

Low Voltage Dimmer Control Guide



Connect your Low Voltage Control Box to a power supply. From any of the 4 Channel ports, using Smart Candle Low Voltage cable wire into dimmer control box. See Fig 1.

Fig 1.




Max 25 Metres Distance

Using Smart Candle Low Voltage Cable, wire the dimmer control box to the candle port box. See Fig 2.

Fig 2.



Max 25 Metres Distance



Using Smart Candle Plug and Go Cables insert into a port on the candle port box and then insert into candle base. 3 metres is the maximum distance a candle can be from the candle port box

Cables available in 0.5 Metres, 1m, 2m or 3m

Maximum 24 Candles Per Dimmer control, Per Output Channel