



Smart Candle

Low Voltage 1-4 Candle System

SC2851



Step 1. Plug in power supply and connect Low Voltage Cable to power supply.



Step 2. Insert Low Voltage Cable into your candle via the plug and go connector.



Step 3. Use Low Voltage Cables to connect up to 4 candles via plug and go connection ports.



IMPORTANT

Designed for use of up to 4 candles ONLY