



# Smart Candle



Low Voltage 20 Candle System

SC2853


**Step 1.** Plug in power supply and insert into to LV20 control box.



**Step 2.** Trim Low Voltage cable as desired. Unscrew fixing screws on control box and insert trimmed cable. Copper into + and Silver into -. Re-screw fixing screws back into place.



**Step 3.** Insert Low Voltage Cable into your candle pod by repeating Step.2



**Step 4.** Add candles into system via either plug and go connection ports or wired connection ports.



### \*\*\*IMPORTANT\*\*\*

This system is designed to run a maximum of 20 candles ONLY.

#### **Note:**

The maximum distance possible to the first candle pod is 25 metres.

Thereafter no more than 2 metres between candles is possible.